

Fitting the engine safety cables

You will find 2 cables connected such that one is looped round and the other fixed at one end to the loop, thus forming a 'lasso'. The other end of this cable should be fitted from the top of the cabin on the same point where the engine frame support tubes are bolted, and come down the length of the support tubes (as shown below). The loop cable, much longer, should be wrapped around the engine between the cylinders (see second diagram at bottom of page).

