

## Changing fuel tank cable fittings

You will need to unbolts the existing fittings from the fuel tank (as shown by the arrow below) and replace the cable fittings with the ones provided in the package. Note: the bolts that hold the fitting to the tank have been glued to make sure they don't loosen with the vibrations. You will need to apply a fair amount of force (by hand) to get them loose. Apply a little araldite to the bolts when you fit them back with the new cables.

